

Printer Settings for TM-T20iii

2.Interface Settings

2.1.Serial Baud Rate

> 38400bps

2.2.Serial Parity

> None

2.3.Serial Handshaking

> DTR/DSR

2.4.Serial Data Bits

> 8 bits

2.5.Serial Data Receive Error

> Print "?"

2.6.USB Class

> Printer Class

2.7.USB Power Saving

> Enabled

2.8.Receive Buffer Capacity

> 4KB

2.9.BUSY Condition

> Receive Buffer Full or Offline

2.10.Auto Line Feed

> Always disabled

2.11.State to cancel buffer BUSY

> Not BUSY = 256 BYTES

2.12.Output Paper-end Signals

> Paper End&Near-end Sensor Enabled

2.13.Error Signal

> Enabled

2.14.Interface Selection

> UIB / Built-in USB

3.Print Density

> +2

4.Print Speed

> Level 9

5.Automatic Reduction of Paper

> No Reduction

6.Auto Paper feed&Cut at cover close

> Enable

7.Character/Column Settings

7.1.Code Page

> Page:PC437 (USA, Standard Europe)

7.2.International Character Set

> USA

7.3. Embedded Font Replacement

7.3.1.Font A Replacement

> Font A (No Replacement)

7.3.2. Font B Replacement

> Font B (No Replacement)

7.5.Paper Width & Print Column

> 80mm / 48 Column

8.Buzzer Control

8.1. Select Buzzer

> Buzzer Disable

8.2.Sound Pattern(Error)

> Default

8.3. Buzzer Frequency (Error)

> Continuous

8.4.Sound Pattern(Auto Cut)

> Pattern A

8.5. Buzzer Frequency (Auto Cut)

> 1 time

8.6.Sound Pattern(Pulse 1)

> Pattern A

8.7 .Buzzer Frequency(Pulse 1)

> 1 time

8.8. Sound Pattern(Pulse 2)

› Pattern B

8.9. Buzzer Frequency (Pulse 2)

> 1 time

8.10. Sound Pattern(Paper End)

› Default

8.11 .Buzzer Frequency(Paper End)

> Continuous

9. Near-end Detection

> Disable

10.Power Supply Unit Capacity

> Level 3(High)