

Current Settings (Mode 1)

There is no "1"

2. Print Density

2.1 - Monochrome

3. Printing Speed

Level 8

4. Serial Interface

4.1 Baud Rate

38400bps

4.2 Parity

None

4.3. Handshaking

DTR/DSR

4.4. Data Bits

8 bits

4.5. Data Receive Error

Print "?"

5. Auto Paper Feed&Cut at cover close

Enable

6. Paper Width

80mm

There is no "7"

8. Default Character

8.1. Code Page

Page0:PC437(USA, Standard Europe)

8.2. International Character Set

USA

9. Embedded Font Replacement

9.1. Font A Replacement
Font A (No Replacement)

9.2. Font B Replacement
Font B (No Replacement)

10. USB Interface Settings

10.1. Class
Printer Class

10.2. USB Power Saving
Enabled

11. Buzzer Control

11.1. Option Buzzer
Disable

11.2. Buzzer Frequency (Error)
Continuous

11.3. Sound Pattern(Autocut)
Pattern A

11.4. Buzzer Frequency(Autocut)
1 time

11.5. Sound Pattern(Pulse)
Pattern A

11.6. Buzzer Frequency(Pulse 1)
1 time

11.7. Sound Pattern(Pulse 2)
Pattern B

11.8. Buzzer Frequency(Pulse 2)
1 time

12. Column Emulation

Off

13. Interface Settings

13.1. Receive Buffer Capacity
4KB

13.2. BUSY Condition
Receive Buffer Full or Offline

13.3. Auto Line Feed
Always disabled

13.4. State to cancel buffer BUSY
Not BUSY = 256 bytes

13.5. Output Paper-end Signals
Paper End Sensor Enabled

13.6. Error Signal
Enabled

There is no #14

15. Logo Emulation

Off

16. Automatic Paper Reduction

16.1 Upper Margin
Enable

16.2. Lower Margin
Disable

16.3. Blank Line Spacing
Not Reduce

16.4. Blank Space
Not Reduce

16.5. Barcode Height
Not Reduce

17. Interface Selection

Auto

18. Power Supply Unit Capacity

Level 3(High)